

Installation Instructions



06'+ Civic Footrest

SK06-HPDL-CFT12

Contents: 1x Footrest
4x Self-tapping screws

Tools Required: Phillips screw driver or power drill with Phillips attachment

Disclaimer: Please use caution and proper safety equipment when using power tools, Strut King and its affiliates are not responsible for any injuries occurred during installation.

1.



Place the stainless steel footrest cover over the existing plastic footrest.

2.



Place the self-tapping screws into the locations shown and use the Phillips screw driver or power drill with Phillips attachment to properly mount the footrest.